

User Manual of Web Client

Index

Chapter 1 Software Installation.....	3
Chapter 2 Begin to Use.....	5
2.1 Login and Exit	5
2.2 Preview Interface Instruction	6
2.3 Preview Image	7
Chapter 3 Playback.....	8
Chapter 4 Remote Configure.....	9
4.1 Sever Parameter	9
4.2 Channel Parameters	10
4.3 Network Configuration.....	14
4.4 Serial Parameters Configuration	16
4.5 Alarm Parameters Configuration.....	17
4.6 User Configuration	19
4.7 Others.....	20
Chapter 5 Log	20

Chapter 1 Software Installation

This web client is embedded in DVR, when you use web browser to get access to DVR, it will be downloaded automatically.

Please decrease the internet security level to make sure that the ActiveX could be downloaded successfully. Open IE browser and select as following steps: Tools→Internet options→security→internet→custom level. As shown in fig 1.1. In the setting list you should enable all the options about ActiveX control.




Fig 1.1

Input the IP address or domain name of DVR and press enter, the interface like fig 1.2 will pop up. If you can see the interface, the ActiveX has been downloaded successfully.




Fig 1.2

Chapter 2 Begin to Use

2.1 Login and Exit

Input username and password correctly to get access to the web client. As shown in fig 2.1.


A login dialog box with a light blue background and a dark blue border. It contains three input fields: 'Username:' with the text 'admin', 'Password:' with masked characters, and 'Port:' with the text '8000'. Below the fields are two buttons: 'OK' and 'Cancel'.

Fig 2.1

After getting access to the web client, you can click logout then click OK in pop-up dialog box to exit. As shown in fig 2.2.































Fig 2.2

2.2 Preview Interface Instruction

1. Device name and channel name
2. Function and configuration column
3. PTZ control column
4. Image adjustment column
5. Function column
6. Preview mode column

1	 Embedded Net DVR  01-Camera 01 : Device name and channel name	4	 : Volume  : Bright  : Contrast  : Hue  : Saturation
2	 Logout :Logout  Preview :Preview  Playback :Remote playback  Log :View log  Configure :Remote Configure	5	 :Start/stop all channel preview  :Capture picture  :Manual record  :Voice talk  : Default values
3	 :PTZ directions & auto scan  : wiper & light <input type="text" value="1"/>  :PTZ preset  Zoom  : Zoom in & out  Focus  : Focus  Iris  : Iris	6	 : Preview mode options

2.3 Preview Image

Step 1 Select a preview mode.

Step 2 Select one split window and double click channel name to start to preview.

Step 3 Right click right key and select main stream and sub stream for previewing, as fig 2.3 shown below:




Fig 2.3

Chapter 3 Playback

Playback interface is shown as Fig3.1.






Fig 3.1

Select channel, click "search" button, all the names of files which meet the time and file type conditions will be displayed in the file list. User can double click the file to play.

Select the single file or several files from the file list, click  to download, the selected files will be downloaded to folder "C:\OCXSaveAllFiles\Record\yyyy-mm-dd (such as 2008-09-28)". A dialog will pop up to inform you that downloading is completed.

Click  to capture the picture, the picture will be placed to the folder "C:\OCXSaveAllFiles\PlaybackCapture\ yyyy-mm-dd (such as 2008-09-28)".

Please refer to Fig 3.2 for the functions of control bar




Fig 3.2

- ① process bar ② pause ③ stop ④ backwards ⑤ forwards ⑥ frame by frame ⑦ picture capture
⑧ save clips ⑨ download files ⑩ mute ⑪ volume

Chapter 4 Remote Configure

Click configure button to enter the Remote parameters configure interface.

4.1 Sever Parameter

The screenshot shows a 'Remote Configuration' window with a green title bar and a close button. It has four tabs: 'Server configuration' (selected), 'Channel configuration', 'Network configuration', and 'COM configuration'. The 'Server configuration' tab contains two sections: 'Server Configuration Information' and 'Server Version Information'. The first section has fields for Server name, Device ID, Channel number, Alarm input number, Server type, Serial number, Cycle record, Enable scaler, HDD number, and Alarm output number. The second section has fields for NIC type, IP address, Subnet mask, Remote host IP, Multicast IP, NAS host IP, MAC address, Port, Gateway, Remote host port, HTTP port, and NAS directory. At the bottom are buttons for 'Restore', 'Reboot', 'Save', and 'Exit'.

Server Configuration Information	
Server name	Embedded Net DVR
Device ID	255
Channel number	16
Alarm input number	16
Server type	DVR_HC_S
Serial number	DS-8016HC-S0220080729ABWR000304736WCVU
Cycle record	YES
Enable scaler	Off
HDD number	0
Alarm output number	4

Server Version Information	
Firmware version	V2.1 build 080813
Hardware version	0x67001782
Encode version	V4.0 build 080902
Front panel version	4

Fig 4.1

There are two parts: server configuration information & server version information.

Server configuration information:

Server name: no more than 32 letters, 16 characters at most.

Device ID: the largest NO. is 255.

Cycle record: if you want to overwrite after the HDD is full, just select "YES", if you want to stop record after the HDD is full, just select "NO".

Enable scalar.

The **channel number**, **HDD number**, **alarm input number**, **alarm output number**, **server type**, **server serial** can't be modified.

IP address, **port** and **subnet mask**: server static IP, port and subnet mask are corresponding. The default port is 8000.

NIC type: here are some options such as 10M/100M Auto and so on.

Multicast IP: when you use the multicast, you should input a D-class IP. Range 224.0.0.0 ~ 239.255.255.255.

Gateway: if client software needs go through the gateway to connect the server, you should input a gateway.

NAS host IP and NAS directory: if using network store server, you can just input the NAS IP and the directory.

Remote host IP and port: IP and port of the PC that used for receiving alarm information.

Http port: applied when you use the IE to access to the server.

The **MAC address** can't be modified.

Server version information:

Firmware version, Hardware version, Encode version and Front panel version can't be modified.

After the configuration is finished, click "confirm". If needs to reboot, just click "Reboot" button.

4.2 Channel Parameters

The screenshot shows the 'Remote Configuration' window with the 'Channel configuration' tab selected. The window contains various settings for a channel, including channel selection, scheduling, motion detection, display options, and video parameters. At the bottom, there is a table for 'Overlay text' with columns for area, x, y, and overlay content. The 'Area 1' checkbox is checked, and its content is 'Camera Input 1'.

	x	y	Overlay content
<input checked="" type="checkbox"/> Area 1	0	0	Camera Input 1
<input type="checkbox"/> Area 2	0	0	
<input type="checkbox"/> Area 3	0	0	
<input type="checkbox"/> Area 4	0	0	

Fig 4.2

Select channel: select one channel of the server.

Channel name: it can be modified, 32 letters or 16 characters at most.

Type: Generally, main stream is used for recording, sub stream is used for network transmission.

Frame type: BBP and P can be selected.

I Frame: can be modified.

Image quality: 6 options (only effective for variable bit rate type).

Frame rate: Full (PAL: 25FPS NTSC: 30FPS), 20, 16, 12, 10, 8, 6, 4, 2, 1, 1/2, 1/4, 1/8, 1/16. (Notice: 15, 18 and 22 are special options which only some special servers have.)

Stream type: if you select "video & audio" in the channel properties interface, then both the video and audio can be recorded, or else you can select "video" only.

Max bit rate: You can select 32kbps, 48kbps, 64kbps, 80kbps, 96kbps, 128kbps, 160kbps, 192kbps, 224kbps, 256kbps, 320kbps, 384kbps, 448kbps, 512kbps, 640kbps, 768kbps, 896kbps, 1Mbps, 1.25Mbps, 1.5Mbps, 1.75Mbps, 2Mbps and user-defined.

Resolution: Default is CIF; other options are QCIF, 2CIF, DCIF and 4CIF. Only QCIF and CIF can be select as it is sub stream.

Bit rate type: Variable and Fixed can be selected.

Recording plan: Enable "schedule" option, you can setup the record time, prerecord time, and post record time. Click "set" button to enter recording schedule setup dialog. Select record mode, if select all day record, only record type can be setup. If finish the setup, click "confirm" button to return. Click "cancel" to return if you do not want to save the configuration.

Pre record time: Recording time options before alarm happened. The options are including no prerecord, 5s, 10s, 15s, 20s, 25s, 30s, maximum.

Post record time: Recording time options after alarm stopped. The options are including 5s, 10s, 30s, 1min, 2min, 5min, 10min.

Setup motion detection, video signal loss, view tamping alarm and privacy mask:

Select an option and setup the corresponding area, schedule and linkage type.

Click "area setup" to enter area setup interface. Shown as fig 4.3




Fig 4.3


Enable set area, press "ctrl" and drag mouse with left key.
Enable "show areas" to display the area. Press OK to confirm.

Click "schedule" to enter schedule setup interface. As shown in fig 4.4.



Fig 4.4

Click “linkage” to enter alarm linkage configure interface. As shown in fig 4.5.



The image shows a software window titled "Motion detect link" with a close button (X) in the top right corner. The window is divided into several sections:

- Alarm Handle Method:** This section contains several checkboxes:
 - ☒ On screen warning
 - ☐ Audible warning
 - ☐ Upload to center
 - ☐ Trigger alarm output:
 - ☐ Send Email
- Record camera:** This section contains a grid of checkboxes for selecting cameras:

<input checked="" type="checkbox"/> Channel01	<input type="checkbox"/> Channel06	<input type="checkbox"/> Channel11	<input type="checkbox"/> Channel16
<input type="checkbox"/> Channel02	<input type="checkbox"/> Channel07	<input type="checkbox"/> Channel12	
<input type="checkbox"/> Channel03	<input type="checkbox"/> Channel08	<input type="checkbox"/> Channel13	
<input type="checkbox"/> Channel04	<input type="checkbox"/> Channel09	<input type="checkbox"/> Channel14	
<input type="checkbox"/> Channel05	<input type="checkbox"/> Channel10	<input type="checkbox"/> Channel15	
- PTZ Link:** This section contains a "Camera" dropdown menu set to "Channel01", and two rows of checkboxes with numeric input fields:
 - ☐ Preset: 0
 - ☐ Sequence: 0

At the bottom of the window, there are two buttons: "All" and "None" (located between the "Record camera" and "PTZ Link" sections), and "Confirm" and "Cancel" buttons at the very bottom.

Fig4.5

Setup OSD properties: you can select whether display OSD, display position, whether display week, OSD properties (opaque & steady, opaque & flashing, transparent & steady, transparent & flashing, no display). OSD type (i.e. date & time display types).

Setup the channel name properties: you can select whether display channel name and the display position).

Overlay text: you can overlay text on the channel, 4 line at most, 44 characters at most for every line.

After setting the parameters, click “confirm”. If the server needs to reboot, just click “reboot” button.

(Notice: the information and channel name in all time record, motion detection record, video loss, privacy mask, and view tampering can’t be copied to the other channels)

4.3 Network Configuration

In the remote configuration, you can click network configuration button to set network parameter. As shown in Fig.4.6.

The image shows a 'Remote Configuration' window with a green title bar and a close button. It has four tabs: 'Server configuration', 'Channel configuration', 'Network configuration' (which is selected), and 'COM configuration'. The 'Network configuration' tab contains several sections:

- NFS configuration Info:** Includes 'Disk NO.' (a dropdown menu showing 'DISK01'), 'Server IP' (a text box with '0 . 0 . 0 . 0'), and 'Directory' (an empty text box).
- IP-Server configuration Info:** Includes 'IP-Server IP' (a text box with '0 . 0 . 0 . 0'), 'PPPoE' (a dropdown menu showing 'Off'), 'PPPoE user' (an empty text box), 'PPPoE IP' (a text box with '0 . 0 . 0 . 0'), 'PPPoE password' (an empty text box), and 'Verify password' (an empty text box).
- DNS server:** A text box with '0 . 0 . 0 . 0' and an 'E-Mail Configuration' button.
- DDNS configuration Info:** Includes 'Server type' (a dropdown menu showing 'www.dyndns.com'), 'Enable DDNS' (a dropdown menu showing 'Off'), 'User Name' (an empty text box), 'Host Name' (an empty text box), 'Password' (an empty text box), 'Verify password' (an empty text box), 'Server Address' (an empty text box), and 'Port' (a text box with '0').
- NTP configuration Info:** Includes 'Enable NTP' (a dropdown menu showing 'On'), 'NTP Host' (an empty text box), 'Check Time' (a text box with '0'), 'Hour' (a text box), 'Time zone:GMT' (a text box with '0'), and 'Minut' (a text box).

At the bottom of the window are four buttons: 'Restore', 'Reboot', 'Save', and 'Exit'.

Fig4.6

1. **NFS configuration Info:** This function can be used with NAS in server configuration, DVR will regard network HDD as local HDD. DVR will send and save the real time image to the appointed network HDD.

Disk NO.: Network HDD No. (Max supports 8 HDDs).

Server IP: The IP of the network storage server.

Directory: The directory for accessing the network storage server.


2. **IP-Server configuration info:** Applicable to the device that not only uses PPPoE dial-up but also resolves the private domain via IP server.

IP-Server IP: resolve the server's IP address, namely the address of server which runs the IP server software.

Enable PPPoE: you can select whether to enable the PPPoE.

PPPoE user name, password, verify password: input the PPPoE user name and password which provided by ISP.

3. **DNS server:** IP address of resolving server.
4. **E-mail configuration:** This function enables image capture and sending emails to designated e-mail address (max 2 e-mail addresses at the same time) when abnormality occurred. As shown in fig.4.7.



The image shows a software window titled "E-Mail Configuration". It contains several input fields and a table. At the top, there are fields for "Sender Name", "Sender Address", "User Name", "Authentication" (a dropdown menu currently showing "YES"), "Password", and "Verify password". Below these is a section titled "Email receiver Info (two at most)" which contains a table with three columns: "No", "Name", and "Email Address". The table has two rows, numbered 1 and 2. Below the table is a "Delete" button and a checkbox labeled "Attachment JPEG". At the bottom, there is an "Email Server" dropdown menu set to "SMTP", followed by a text input field, and a "JPEG Capture" dropdown menu set to "2s". "Confirm" and "Cancel" buttons are at the bottom right.

No	Name	Email Address
1		
2		

Fig.4.7

Sender Name: Name appears in Email

Sender Address: Sender Email address

User Name: Email account user name

Authentication: If your Email server asks for a user name and password when sending Email, you need to tick this check box

Password: Email account password & Verify Password.

Mail receiver name: The name appears in Email

Mail receiver address: Receiver Email address

Attachment JPEG: Sending the Email with JPEG picture capture when abnormality occurred.

Email server: SMTP supported Email sending server

JPEG Capture Interval.

5. **DDNS configuration info:** Currently supports two protocols provided by DDNS service supplier.

Server type: server address that provided by carrier like www.dyndns.com or www.peanuthull.com.

Enable DDNS.

User name and password: The user name and password of your DDNS account get from DDNS service supplier.

Host name: The domain name register by yourself on the web site of dyndns or peanuthull.

Server address: The DDNS server provided by DDNS service supplier

Server Port: Provided by the supplier.

6. **NTP configuration info:** NTP is used for synchronizing time with time server, time server is provided by NTP service provider: time.windows.com which is a famous time server provided by Microsoft.

Enable NTP.

NTP Host: NTP server name.

Check time: time interval for checking time automatically.

Time zone: the gap between the system time and Greenwich Mean Time.

4.4 Serial Parameters Configuration

Select “COM configuration” in the remote configuration, show as fig 4.6.

In this interface, you can setup the parameters of 232 and 485.

After the configuration, click “confirm”. If needs to reboot the server, just click “reboot” button.

The screenshot shows a 'Remote Configuration' window with a green title bar and a close button. It has a tabbed interface with 'COM configuration' selected. The window is divided into two main sections: 'RS232 Configuration Information' and 'RS485 Configuration Information'. The RS232 section includes fields for Baud rate (115.2k), Data bits (8), Stop bits (1), Parity (None), Flow control (None), Work mode (Console), PPP (Active), Callback (By dialer), User name, Password, Remote IP, Local IP, Subnet mask, and Phone. The RS485 section includes fields for Channel No. (Channel01), Baud rate (9600), Data bits (8), Stop bits (1), Parity (None), Flow control (None), PTZ type (YouLi), PTZ address (0), and a 'Copy To' dropdown set to 'All channels' with a 'copy' button. At the bottom, there are buttons for 'Restore', 'Reboot', 'Save', and 'Exit'.

Fig 4.6

4.5 Alarm Parameters Configuration

Select “alarm configuration” in the remote setup interface. Show as Fig 4.7.

You can remote setup DVR sensor alarm parameters and the exception parameters.

The image shows a 'Remote Configuration' window with a green title bar and a close button. It has four tabs: 'Channel configuration', 'Network configuration', 'COM configuration', and 'Alarm configuration' (which is selected). The 'Alarm configuration' tab is divided into three sections: 'Alarm input', 'Alarm output', and 'Exception Configuration'.
Alarm input section: Includes a dropdown for 'Alarm input' (set to 'Alarm input 01'), a text field for 'Alarm name' (set to 'Alarm in channel 1'), and a dropdown for 'Alarm type' (set to 'Normal open'). There are checkboxes for 'Method' (checked) and buttons for 'Schedule' and 'Linkage'. A 'Copy To' dropdown is set to 'All alarm input' with a 'copy' button.
Alarm output section: Includes a dropdown for 'Alarm output' (set to 'Alarm output 01') with a 'Schedule' button, and a dropdown for 'Alarm output time' (set to '5 seconds'). A 'Copy To' dropdown is set to 'All alarm output' with a 'copy' button.
Exception Configuration section: Includes a dropdown for 'Exception type' (set to 'Hard disk full'). Below it are checkboxes for 'On screen warning', 'Audible warning', 'Upload to center', 'Trigger alarm output' (checked), and 'Send Email'. At the bottom of this section are checkboxes for 'Output1' (checked), 'Output2', 'Output3', and 'Output4'.
At the bottom of the window are four buttons: 'Restore', 'Reboot', 'Save', and 'Exit'.

Fig 4.7

Alarm input response policy:

Select “Method” option, click “alarm time” button to enter alarm response policy setup interface shown as Fig 4.8.




Fig 4.8

Click “Linkage” button to enter alarm linkage type configuration interface, shown as fig 4.9.




Fig 4.9

Alarm output policy setup:

Click “alarm time” to setup alarm output schedule.

Exception Config:

The Exception configuration includes HDD full, HDD error, network broken, illegal access, video standard not matched, etc, also you can setup exceptions response policy.

4.6 User Configuration

In this interface you can remote setup DVR users, including username, password, user rights, etc.

Check the user right when you select the user.

If the user exists, just right click the user and click “modify” in the popup menu. Select “cancel” to return.

After finish, click “OK”, “Save Para.” button. Please reboot DVR to make the new parameter become effective. Shown as fig 4.10




Fig 4.10

4.7 Others

User can remote upgrade server or format Hard Disk in this interface. Shown as fig 4.11.

Select “Remote Upgrade”, single click “Explore”, select upgrade file. Click “Upgrade” to begin upgrade process. After completing upgrade, status tray will show “Status: Server Upgrade finish”.

Select “Format Hard Disk”, select the disk you want to operate on (all or only one disk of them), single click “Format”, the system will indicate that Format is under process. After the process, it will indicate “Format Hard Disk Successful”.

NOTE: After the formation of hard disk, a reset of the equipment is indispensable. No other operations are allowed during the formation process.





Fig 4.11

Chapter 5 Log

Select search type, start time and stop time then click  to search. Shown as fig 5.1




Fig 5.1