



X-SERIES



RV-PED

INSTALLATION SHEET

BRACKET INSTALLATION


Fixings to mount the Pedestal bracket will depend upon the fixing surface. It is important to use adequate quality fixings to safely support the complete Ball PTZ assembly. Fixing slots on 4" PCD provide adequate clearance for 6mm bolts.

FLYING LEAD INSTALLATION


Install the Fly Lead optionally through the Central Mounting Tube or via a 20mm Gland Entry Point.

Note: the Gland Entry is supplied with a 20 x 1.5mm thread to accommodate industry standard 20mm Glands.

ATTACHING THE BALL PTZ TO THE PEDESTAL BRACKET

1. Remove Pedestal Mount Cover by releasing Allen Screws.
2. Fully unscrew Hand Lock Nut. 
3. Offer Camera to Bracket. Please Note: The Mounting Boss orientation is IMPORTANT and should match the picture in FIG 1. The FLAT edge must be positioned at the rear and the RETAINING LUGS engaged in the Boss Cut Outs.
4. When tightening the Hand Lock Nut support the Dome with hand.

FINAL VISUAL CHECK BEFORE REPLACING COVER & POWER UP, FIG 3.

1. Mounting Boss should sit behind Retaining Lugs.
2. The Hand Lock Nut should be fully Locked & Tightened. 
3. The Clearance is even throughout 360° rotation and the camera is free moving.
4. Replace Pedestal Mount Cover.

CONTENTS

- Pedestal Bracket Assembly • 10m Fly Lead • 4mm Allen Key

