

BQT EIP701 EasyView IP Client

To view a video demo of Easyview in motion click [here](#)The EasyView® IP Client is an advanced Graphical User Interface Client program that provides control over EasyView® NVR Server products such as the EIP601/EIP602 series. Key features:

- Integration with BQT's EIP601/EIP602 EasyView® NVR Server
 - Advanced Alarm handling
 - Drag-and-drop camera selection
 - Easy to configure and operate
 - PTZ Control
 - Sequences and macros
 - Customizable screen layout
 - Operator log
- Integration possibilities The EasyView® IP Client software is the ideal operator platform to be used in conjunction with one or multiple BQT EasyView® NVR Servers. Video viewing The video signals from the attached devices are viewed in a video window. The video window can be set to show either a single camera or a 4, 9 or 16-split. Alarm handling The alarm handling is designed to provide the operator with a fast and easy-to-understand overview of the alarm status. All incoming alarms can be prioritised so that the most important alarms automatically overrule the less important alarms. At the same time, the alarm list constantly shows the operator which alarms still needs to be responded to and he can thereby easily switch between the various alarms in order to provide the fastest alarm response. The alarm handling includes selection of up to 16 BQT IP cameras/encoders which can come from any source, i.e. they need not come from the same equipment that raised the alarm. PTZ presets as well as output relays can also be activated automatically upon an alarm. The alarm clearing can be set to follow the alarm input or be forced to be cleared by the operator. All alarms are logged in a file with information such as time/date, alarm source, when and how the alarm was cleared etc. Time zones (days, hours) can be defined in which certain alarms can be disabled. Macros

EasyView® IP Client offers programmable macros which can automate the operation of a system. The macros can be programmed with functions such as camera selection, call of presets and activation of contact outputs. Operator Log

This log can keep track of the operations of each operator logged into the system. This feature is very suitable for alarm handling centres where e.g. a customer can be charged according to the actual workload. Languages

EasyView® IP Client is currently available in English only. Configuration

EasyView® IP Client is designed to be easy to configure. Most of the configuration can be done by wizards which guides the installer through the configuration. Supported Cameras

EasyView® IP Client supports access of up to 999 BQT IP cameras allowing you to handle numerous units of BQT's EIP601/EIP602 EasyView NVR Servers from the same EasyView Client.