





## VIDOS Server



- ▶ **Unlimited number of users**
- ▶ **User management with 32 user groups**
- ▶ **Device Access Control**
- ▶ **Hierarchical server structure**
- ▶ **Up to two backup servers per server**
- ▶ **Standard database access**
- ▶ **Event logging and management**

VIDOS Server is the powerful heart for professional IP security, video surveillance and alarm management solutions. In combination with VIDOS clients, it enables users to manage and operate complex client/server applications. VIDOS Server ensures that these mission critical applications use full server redundancy to maintain extremely high levels of reliability.

As part of the VIDOS Pro Software Suite, VIDOS Server allows centralized management and control in a hierarchical structure. This enables an administrator to set different authorisation levels or privileges for user groups that are the basis for all VIDOS clients and users for access to configuration, live viewing, PTZ control, recording and retrieval.



A VIDOS Server can be configured to be master server and/or user server, which has the purpose to provide a single central location for all users and user groups. Both configuration types may be backed-up by other servers configured as backup servers.

A VIDOS Server can also have connections to other master servers, thus enabling CCTV system designers to create complex, far-reaching and redundant surveillance networks with still a unique configuration throughout the system.

Together with the other powerful components in the VIDOS Pro Software Suite, including the Configuration Manager, VIDOS, VIDOS Lite Viewer, Archive Player and Exporter and VIDOS Monitor Wall applications, it is ideally suited for CCTV applications of any scale.

VIDOS Server is available as software that can be licensed to support a virtually unlimited number of users. It can be installed on a VIDOS client workstation and, depending on the performance required, run in the background of VIDOS client, or on a stand-alone server. For added convenience there is also a choice of pre-configured hardware solutions.

## Technical Specifications

### System Requirements

Hardware	Personal Computer
CPU	Pentium IV, 1.8 GHz or better
Hard Disk Interface	IDE or better
RAM	256 MB
OS	Windows XP Home/XP Professional Windows 2000 SP3 32-bit Windows Server 2003 32-bit
Ethernet Card	100 Mb
Free Memory (Inst.)	75 MB (VIDOS Server, Configuration Manager, .NET environment, MPEG ActiveX)

### Software Features

User Management	32 user groups Unlimited numbers of users Priorities of each user group (dynamic access rights)
Device Management	List of devices that belong to this server Privileges per camera for each user group (static access rights) User Group privileges can be set to - Live viewing - View and PTZ control - Overrule - No Access

Structure	Hierarchical structure with connections to multiple other master servers Central user server to get user groups and users from Up to 2 backup servers per master or user server
Configuration	Through Configuration Manager

## Ordering Information

<b>VIDOSPRODEMO VIDOS Pro Demo Package</b> VIDOS Pro Trial versions inclusive printed documentation and CD	<b>VIDOSPRODEMO</b>
<b>VIDOSSRV10CAM VIDOS Server Base Pack</b> VIDOS Server Base Pack with 10 Cameras License	<b>VIDOSSRV10CAM</b>
<b>VIDOSSRV-5P VIDOS Server Base Pack 5-pack</b> VIDOS Server License Base Pack with 10 Cameras License 5-pack	<b>VIDOSSRV-5P</b>
<b>VIDOSSRV-10P VIDOS Server Base Pack 10-pack</b> VIDOS Server License Base Pack with 10 Cameras License 10-pack	<b>VIDOSSRV-10P</b>
<b>VIDOSSRVBK VIDOS Backup Server</b> VIDOS Backup Server License	<b>VIDOSSRVBK</b>
<b>VIDOSSRVBK-5P VIDOS Backup SRV 5-pack</b> VIDOS Backup Server License 5-pack	<b>VIDOSSRVBK-5P</b>
<b>VIDOSSRVBK-10P VIDOS Backup SRV 10-pack</b> VIDOS Backup Server License 10-pack	<b>VIDOSSRVBK-10P</b>
<b>VIDOS SRV 16 CAM UPGR</b> VIDOS Server Upgrade License by 16 Cameras (e-license)	<b>VIDOSSRV16CAM</b>
<b>VIDOS SRV 50 CAM UPGR</b> VIDOS Server Upgrade License by 50 Cameras (e-license)	<b>VIDOSSRV50CAM</b>
<b>VIDOS SRV 100 CAM UPGR</b> VIDOS Server Upgrade License by 100 Cameras (e-license)	<b>VIDOSSRVCAM100</b>
<b>VIDOS SRV 250 CAM UPGR</b> VIDOS Server Upgrade License by 250 Cameras (e-license)	<b>VIDOSSRVCAM250</b>
<b>VIDOS SRV 500 CAM UPGR</b> VIDOS Server Upgrade License by 500 Cameras (e-license)	<b>VIDOSSRVCAM500</b>

**Americas:**  
Bosch Security Systems, Inc.  
130 Perinton Parkway  
Fairport, New York, 14450, USA  
Phone: +1 800 289 0096  
Fax: +1 585 223 9180  
security.sales@us.bosch.com  
www.boschsecurity.us

**Europe, Middle East, Africa:**  
Bosch Security Systems B.V.  
P.O. Box 80002  
5600 JB Eindhoven, The Netherlands  
Phone: +31 40 2577 284  
Fax: +31 40 2577 330  
emea.securitysystems@bosch.com  
www.boschsecurity.com

**Asia-Pacific:**  
Robert Bosch (SEA) Pte Ltd, Security Systems  
11 Bishan Street 21  
Singapore 573943  
Phone: +65 6258 5511  
Fax: +65 6571 2698  
apr.securitysystems@bosch.com  
www.boschsecurity.com

### Represented by