# ACS5000-EXP/ACS5008-EXP Expansion Chassis



The ACS5000-EXP and ACS5008-EXP expansion chassis provide a complete UL listed enclosure and power supply to house and power ACS5000-DB and ACS5000-IO expansion boards. Up to two ACS5000 expansion boards can be mounted into the ACS5000-EXP chassis and up to four ACS5000 expansion boards can be mounted into the ACS5008-EXP chassis.





#### **Ordering Information**

- ACS5000-EXP Expansion chassis (2 board enclosure)
- ACS5008-EXP Large expansion chassis (4 board enclosure)

### Ordering Information – Associated ACS5000 Series Components

- ACS5000-DB ACS5000 Dual reader expansion board
- ACS5000-IO ACS5000 Input/Output expansion board

#### **Service and Support**

- Toll-free telephone and email support
- User manual, online help, and installation guide
- Professional services available for fast and seamless system implementation; options include:
  - training
  - technical support
  - conversion of legacy systems and databases
  - custom branding

## ACS5000-EXP/ACS5008-EXP Expansion Chassis

### **ACS5000-DB Expansion Board Specifications**

Specification Details
[ACS5000-EXP – 2 boards] [ACS5008-EXP – 4 boards]
12VDC @ 3A (supports expansion boards and readers only); aux output – 12VDC @ 250mA (not to be used for lock power)
16.5VAC 40VA
[ACS5000-EXP (1) 12VDC 7Ah Rechargeable] [ACS5008-EXP (2) 12VDC 7Ah Rechargeable]
Operating Temp: 32° to 125° F, (0° to 49° C); Humidity: Max 85% non-condensing
Listed 33HR   Access Control UL294/ULC Listed, CE Certified
[ACS5000-EXP - 15"h x 15"w x 3.75"d]
[ACS5000-EXP - 15"h x 15"w x 3.75"d] [ACS5008-EXP - 23.5"h x 15"w x 3.75"d]

#### Powerful security made simple.

Learn more at www.brivo.com/demo or email demo@brivo.com to arrange a personal demonstration.

