

PMS Central™ DATA SHEET

PMS Central software controls the Sony PMS-500 and 400 video transmission products. The software can be used on a standard PC to make it easy to dial sites and control the cameras on those sites. An optional video card will allow the received pictures to be displayed on the PC monitor or captured to the PC hard disk.

Each site will also have a map layout for camera selection making it easy for the operator to know where each camera is on site. This layout appears automatically when an alarm call comes in to the monitoring station giving instant recognition of the site and where the problem is. Keyholder and action details are also displayed at this time.



Camera control is enhanced by an on screen joystick or by using an external PC joystick.

PMS Central has sophisticated logging of all operations to a chosen PC. This means that reports show operations from all operators on the network and not just one PC.

Main features are:

- ◆ Central station control software for PMS - 500 / 400
- ◆ Map layout display of each site
- ◆ Optional video picture on PC Monitor
- ◆ Pan and tilt control with on-screen buttons or PC Joystick
- ◆ Easy site setup and dialling
- ◆ Upload / download of all PMS settings and setup.


PMS CENTRAL software can be utilised in English, French, German, Italian, Spanish, Swedish or Finnish.




<u>Hardware / Software</u>	<u>Requirements</u>
PC Ram	8 MB or above
PC & Display	Pentium 75Mhz or higher with 256 colour VGA or SVGA. Pentium 166 or higher Recommended
PC Hard drive	8 MB or above free
PC Floppy drive	3.5" 1.44MB
PC Pointing device	MS mouse, touchscreen or Compatible pointing device
PC Parallel port	1 parallel port
PC RS232 Communications ports	1 mouse / Touch Screen port. 1 serial port for PMS. 1 serial port for RS232 VCR.
PC Graphical environment	MS Windows 3.0 or above, Windows 95, Windows 98 or NT
PC Operating system	MS DOS 6.0 or above
Video capture card	CCTVGRAB, for use with Windows 95 only. PCI slot. For best results VGA card must have direct draw capability. Pentium 75 (min.) with 16 bit colour recommended.
VCR's controllable	SONY SVT-1000P, SVT-5050P, SVT-S3050P All above with RS232 option
TRANSMISSION EQUIPMENT	SONY PMS / RSE Transmission Range
CCTV Software Required	Links to Camfunction to control Domes or PTZ Cameras Use with 'plus' or 'studio' software to control equipment on remote site.

Controlling a VCR on remote site Via PMS using PMS Central

PC Fitted with **PMS Central** software enables control of a VCR on the camera site. The VCR can be used for local archiving of the cameras or can be switched to record by the PMS operator.



Controlling Uniplex Via PMS using PMS Central and Uniplus



SONY

FMS
Central/UPX.V9D

PMS CENTRAL is a

product

Tel:	01704 548675	CCTV SOFTWARE LTD
Fax:	01704 548679	37 CHAMBRES RD
International Tel:	+44 1704 548675	SOUTHPORT
International Fax:	+44 1704 548679	MERSEYSIDE
Internet WWW:	http://www.cctvsoftware.com	PR8 6JG
e-mail	cctvsoftware@compuserve.com	U.K
		REF:PMSCENTRAL 0499