



**DSX Access Systems, Inc.**

## **DSX Enrollment Reader**



- **USB Connected**
- **125KHz or 13.5MHz Versions**
- **Formatted for WinDSX**
- **Inserts Card Number in Code field**
- **Allows for quick and consistent entry of card numbers**
- **LED flashes and beeps when card is read**

## DSX Enrollment Reader

### Size

4.2"W x 2.5"H x .875"D

### Weight

.45lbs

### Power Requirements

USB

### Warranty

Limited 1 Year

### Frequency

13.56 MHz or 125KHz

### Compliance

FCC, RoHS

### Enrollment Reader

This USB reader is preprogrammed by DSX to properly read the card number and insert the proper data into the WinDSX database.

### Requirements

Connect the USB enrollment reader to an available USB port on the PC that will be entering the card numbers in to the WinDSX software.

### Enrollment Process

Add or Edit a card holder. Advance to the Card screen and click on the Code field.

Once the cursor is in the Code field – Present the Card to the Reader.

**New Cardholder New Card**

Cards | Access Level: | Linking Level: |

Code #: [ ] P.I.N.#: [ ]

Imprinted Card #: [ ] # of Uses Allowed: 9999

Start Date: 09/28/2010 Stop Date: 12/31/9999

Start Time: 12:00:00 AM Stop Time: 12:00:00 AM

Guard Tour:  Override Anti-Passback:

Status:

Date Last Used: 01/01/1000 Anti-PassBack Status: N N N N

Last Used At: Loc: 1 0 Z1 Z2 Z3 Z4

Notes: [ ]

Previous Next Cancel OK

Once the Card is presented and the number is displayed in the Code Field Click OK to Save.