



DSX Access Systems, Inc.

Workstation Startup Map

Workstation Startup Map Parameters

There is a new feature that allows Workstation to display a map at startup. This can be used where the Map is to always be displayed such as on large monitors in a security office.

To configure this feature, close the program on the PC where it is to be used. Browse to the WinDSX\RunData\ folder. Locate the WS_Settings.txt file and open. Scroll to the bottom where you will find the new entries regarding the Startup Map.

Startup Map Name
Startup Map Is Maximized
Startup Map X Position
Startup Map Y Position
Startup Map Save Changes

Map Name is the name assigned to the map within the WinDSX database.

Map is Maximized can be set to YES to have the MAP shown full size.

Map X and Y positions let you set where it is to be displayed.

Map Save Changes can be set to YES so that once the program is running and the MAP is displayed you can move it to where you want it to be and size it. Once closed, it will start back up in that same position. You can enable save changes, start the program, position the map, close the program, set the Save Changes back to NO and it will always come up in the place you specified.