

StarNeT™ 1000 Security Management System (SMS)

Description – Senstar's StarNeT™ 1000 is a Windows®-based multi-functional software package offering three important capabilities:

- Security Management System (SMS)
- Out-of-the-box integration with a broad range of Senstar products
- Set-up and configuration tool for Senstar's Perimitrax®, Intelli-FLEX™, and IntelliFIBER™

Senstar's StarNeT 1000 is a field-proven package with hundreds of installations world-wide that are protecting a wide-range of critical facilities from threats to human safety and property.



Features

- Multi-functional package integrating security management, field network control and sensor configuration
- Powerful point-and-click user interface with optional touch screen support
- Customizable screens and event processing
- Supports Senstar Crossfire™, Sennet® and Silver Networks™
- Configuration tool for Perimitrax, Intelli-FLEX and IntelliFIBER sensors
- Runs on Windows® XP Pro

Benefits

- Compatibility with Senstar security equipment reduces system integration time and risk
- Customized screens enable optimum security personnel effectiveness
- Cost-effective for any size system

Markets

- Airports
- Government agencies and laboratories
- Correctional facilities
- Power generation sites
- Commercial and industrial sites
- Equipment and storage yards
- Electric and gas distribution
- Military bases
- Private estates / VIP residences
- Communications sites
- Petrochemical
- Sensitive government sites

StarNeT 1000

Security Management System (SMS)

StarNet 1000 SMS

As a security management system, StarNeT 1000 displays site information on site-specific maps and / or images and enables point-and-click control of all security system components via menus and screen icons. Using StarNeT 1000, security personnel can:

- View alarms as they occur and acknowledge and reset them as appropriate
- View site-specific maps or images showing the location of sensors and their corresponding detection zones
- Be alerted to alarms or other system events with audio prompts
- Enable or disable sensors
- Control system hardware (doors, lights, CCTV, intercom, etc.)
- Generate reports of system activity and equipment status
- Perform guard tours

Security operators do not require special computer skills and quickly adapt to StarNeT 1000 as it was designed with ease-of-use in mind. Operator keyboard interface is required for only a few administrative functions and most interaction is via an intuitive mouse, trackball, and / or touchscreen interface. This greatly increases the speed and accuracy of operator response to emergencies while simultaneously minimizing training costs.

Senstar's StarNeT 1000 Security Management System (SMS) is flexible enough to suit any site from a simple standalone system to a multiple workstation, multiple site application with full hardware redundancy. A StarNeT system can be expanded, upgraded or modified at any time and is supported by Senstar, the world's leading supplier of outdoor security solutions.

StarNeT 1000 allows system integration personnel to develop the specific user interface screens and operating modes desired and to assign security personnel appropriate password-controlled priority levels for access to menus, features, and controls. SIMPL™, the system configuration component of StarNeT 1000, provides a powerful but easy-to-use tool for system design.

A menu-driven point-and-click design approach has resulted in ease-of-use without compromising features. Default screen icons can be used to represent site alarm and control points thereby providing rapid "out-of-the-box" functionality or they can be fully customized with different graphics, functionality and associated .wav files (for audio event prompts). An icon copy capability greatly speeds up site creation. Icons can also have associated processes that use Boolean logic and macro-like features to create powerful automated relationships between I/O points.

Other important features of SIMPL include:

- Default icon library with automatic processes for standard door control functions including interlock support, perimeter sensors, fire alarms, interior sensors, guard tour, CCTV call up, intercoms and nurse call. All processes are customizable to meet unique customer requirements.
- Example ".wav" files that can be associated with alarm/operator events. Additional WAV files can be imported or created using standard audio recording programs and a microphone (not included).

StarNeT 1000 interface capabilities

StarNeT 1000 provides seamless connectivity to a range of Senstar field networks, a general-purpose software interface called Network Alarm Interface for communications with other security management software, and interfaces to various third-party video matrix switches. The Senstar field networks supported include Crossfire, Sennet and Silver, each of which provides a highly reliable means for connecting field equipment to a central SMS.

Crossfire Network

Crossfire works in a loop topology with separate transmit and receive point-to-point links between each piece of connected field equipment. Crossfire networks are designed to be polled from both ends of the loop, thus providing redundant data paths to the field equipment. Point-to-point links can be RS-422 or multi-mode fiber optic. Up to 128 field units can be connected with Crossfire. Using

Crossfire, StarNeT 1000 can receive alarm and status inputs and set control outputs for Intelli-FLEX, IntelliFIBER and MPS-4100 sensor processors equipped with the Crossfire communications option and for the Crossfire series of Input / Output transponders. For interfacing a PC running StarNeT 1000 to a Crossfire™ network, Senstar recommends the redundant switcher / data converter unit, part number J4KT0500.

Silver Network


Silver Network uses a loop topology with separate transmit and receive point-to-point links between each piece of connected equipment. Silver Networks are designed to be polled from both ends of the loop, thus providing redundant data paths to the field equipment. Point-to-point links can be RS-422, single or multi-mode fiber, or over OmniTrax® sensor cables. Up to 32 field units can be connected with Silver Network. Using Silver Network, StarNeT 1000 can receive alarm and status inputs and set control outputs for OmniTrax and XField® processors equipped with a Silver Network communications card. OmniTrax support includes receiving ranging information. To interface a PC running StarNeT 1000 to Silver Network, a Silver Network Interface Unit (SNIU) is required along with the Silver Network Manager software package.

Sennet Network


Sennet networks use a logical multi-drop communication protocol. Dual physical data paths are incorporated for redundancy. Sennet network interconnects can be RS-485, multi-mode fiber optic, or run over Perimitrax sensor cables. Up to 62 field units can be connected with a Sennet network. Using Sennet, StarNeT 1000 can receive alarm and status information and set control outputs for Perimitrax processors, the Sennet Transponder Unit (TU) and Large Transponder Unit (LTU), and Intelli-FLEX and IntelliFIBER processors equipped with the Sennet communications option. To interface a PC running StarNeT 1000 to a Sennet network, a Sennet Network Controller is required.

StarNeT 1000

Network configuration



Applications:



Technical Specifications

NETWORK ALARM INTERFACE (NAI)

StarNeT 1000's Network Alarm Interface (NAI) provides an easy-to-use software interface between StarNeT 1000 and any other software program to which there is a TCP / IP communications path. Such other software can include a 3rd party security management system or another copy of StarNeT 1000 running on either the same computer or on a separate computer.

Using NAI, a StarNeT 1000 workstation directly controlling security equipment networks can distribute the alarm and status information being collected to other software programs. NAI provides an easy-to-use software interface and works over a standard TCP / IP connection.

Senstar provides full documentation and a Dynamic Link Library (DLL) that simplifies software integration for third parties using NAI.

VIDEO MATRIX SWITCHES

StarNeT 1000 supports a range of video matrix switches from manufacturers including American Dynamics, Bosch, and Pelco. Contact your Senstar representative for specific models supported.

SET-UP & CONFIGURATION TOOLS

StarNeT 1000 includes set-up and configuration tools for Perimitrax, Intelli-FLEX and IntelliFIBER sensor processors when networked with either Crossfire or Sennet networks, and for the Sennet Network Controller TV and LTU. Once the sensor processors are installed and have their network address set all further set-up and configuration can be done via StarNeT 1000. This includes viewing and setting thresholds, verifying communications, configuring the operation of input and output points, and recording Perimitrax, Intelli-FLEX and IntelliFIBER sensor-response plots. StarNeT 1000 is also integrated with Senstar's Universal Configuration Module (UCM) software so that from the StarNeT 1000 operator screen, an operator with a suitable password can invoke the UCM and perform configuration on OmniTrax and XField sensor processors.

STARNET 1000 PLATFORM COMPATIBILITY

StarNeT runs on Windows® XP Pro meaning that it can run on the vast array of Windows®-compatible hardware platforms and use any Windows®-supported serial I/O card, network card, or monitor including touchscreen monitors.

STARNET 1000 VERSIONS

StarNeT software is available in large and small versions that can communicate with up to 128 or 32 transponders respectively.

STARNET 1000 SOFTWARE / HARDWARE BUNDLES

Both the large and small StarNeT 1000 versions are available pre-installed on a current generation desktop computer. Each bundle includes Windows® XP Pro, a 19" LCD monitor, and a pair of RS-232 to RS-422 adapters for interfacing StarNeT 1000 to a Crossfire network. Upgrade options include:

- 19 in. rack mounted industrial PC
- A variety of sizes of desktop and rackmount LCD and SVGA monitors with and without touchscreens.

Specifications are subject to change without prior notice.



www.senstar.com

ISO 9001:2000
CGSB Registered Certificate 95711
DAS-530-IN-R1-E-07/08

Copyright ©2008. All rights reserved. Features and specifications are subject to change without notice. Intelli-FLEX, StarNeT and IntelliFIBER are trademarks of Senstar-Stellar Corporation, Sennet, OmniTrax, XField, Senstar-Stellar and the Senstar logo are registered trademarks of Senstar-Stellar Corporation.

Printed in Canada

Senstar is represented by dealers in over 80 countries.

International
Carp, Ontario, Canada
Tel: +1 (613) 839-5572
info@senstar.com

United States
Fremont, CA, USA
Toll Free: +1 (800) 676-3300
mkt@msi-usa.net

United Kingdom
Worcs., UK
Tel: +44 (0) 1386 834433
senstaruk@senstar.com

Latin America
Cuernavaca, México
Tel: +52 (777) 313 0288
info@senstarstellar.com.mx

Europe
Markdorf, Germany
Tel: +49 7544-95910
info@senstar.de

Brazil
São Paulo, Brasil
Tel: +55 (11) 4195-1020
info@senstarstellar.com.br