

Premier Expanders

A complete range of expansion modules allows modular system design, ensuring maximum flexibility and future-proof installations.



Premier 4XP G3

Remote Zone Expander for use with the Premier Series. Provides an additional 4 programmable DP or EOL zones and 2 programmable outputs. Module replaces two keypads for additional zone expansion.

Premier 8XP G3

Remote Zone Expander for use with the Premier Series. Provides an additional 8 programmable DP or EOL zones, 8 programmable outputs, 1 auxiliary input and a speaker driver output with programmable volume control.



Premier 8X G3

Remote Zone Expander for use with the Premier International Series. Provides an additional 8 programmable EOL zones, 2 programmable outputs and a speaker driver output with programmable volume control.

Premier 8XE G3

Local plug-on Zone Expander for use with the Premier International Series and Premier 24 control panel. Provides an additional 8 programmable EOL zones.



Premier OP8 G3

Plug-on Output expander for use with the Premier Series control panel. Provides an additional 8 programmable outputs, each rated at 100mA negative applied.

Premier OP16 G3

Remote Output expander for use with the Premier Series of control panels. Provides an additional 16 programmable outputs, each rated at 100mA negative applied.



Premier 24iXD G3

24 zone iD[†] expansion module for use with the Premier 24 control panel.

Premier 60iXD G3

Expansion module providing two iD[†] loops each supporting 30 iD[†] biscuits. Includes fused 12V output for powering detectors plus engineer's keypad port for local iD[†] diagnostics.



Premier PSU200XP G3

Premier 8XP expander with 2 Amp power supply module which is fully monitored by the host control panel.

Premier RM8 G3

Relay Module for use with the Premier Series and Premier International Series of control panels. Provides 8 additional relay switch outputs.



[†] iD is a trademark of Novar Systems Ltd.

Features & Functions

	Premier 4XP	Premier 8XP	Premier 8X	Premier 8XE	Premier OP8	Premier OP16	Premier RM8	Premier 24iXD	Premier 60iXD
Premier Series Compatible	•	•		• ^{††}	•	•	•	• ^{††}	•
Premier International Series Compatible			•	•			•		•
Additional Zones	4	8	8	8				24	60
Additional Outputs	2	8	2		8	16			
Auxiliary Inputs		1							
Speaker Driver	•	•	•						
Relay Outputs							8		
Remote Wired	•	•	•			•	•		•
Plug-On				•	• ^{††}		• ^{†††}	•	• ^{†††}
EN 50131-1	G3	G3	G3	G3	G3	G3	G3	G3	G3
EN 50131-3	G3	G3	G3	G3	G3	G3	G3	G3	G3

^{††}Premier 24 Only. ^{†††}Premier Series Only (except Premier 24).