

# Intrusion Panels

## IC60 Accessories

### Expander and Relay Modules



Type

Order No.

IZE6-04



#### Four wired zone expander module

With this unit, 4 additional wired zones can be connected to the IC60 control panel. The module can be integrated within the control panel (modular version) or mounted externally (compact version) to save cabling via a connection to the terminal block of the inputs. Up to 4 modules can be used with one IC60 panel (e.g. max 16 wired zones).

Power supply	Connected to zone
Current consumption	Resistor only / no power
Operating temperature	-10 ~ +50 °C
Storage temperature	-20 ~ +60 °C
Housing	No housing
EMI rejection	Up to 2GHz > 10V/m
Humidity (EN60721)	< 85% r.h., non condensing
LCD Display	None
Dimensions (W x H x D)	45 x 31 x 12 mm
Data sheet	009093

A5Q00020291

IRO6-04



#### Relay output module 4 x 12V / 1A

The IRO6-04 is an external relay output module for IC60 with 4 Relays (12V/1A). With this unit 4 additional output relays can be connected to the IC60 control panel. The module can be mounted externally to save cabling, via a connection to the central bus (modular version). UP to 2 modules can be used with each IC60 panel (e.g. max. 8 programmable outputs).

Power supply	11 - 16 VDC (via central bus)
Current consumption	Active: 20 mA per active relay Standby: 15 mA
Outputs	4 x relay 12 VDC / 1 A 4 x open collector 12 VDC / 0.1 A
Operating temperature	-10 ~ +50 °C
Storage temperature	- 20 ~ +60 °C
Housing	No housing built-in modular unit
EMI rejection	Up to 1 GHz >10 V/m
Humidity (EN60721)	< 85% r.h., no condensation
Dimensions (W x H x D)	102 x 59 x 16 mm
Data sheet	009093

A5Q00013944