




# RF1100E Glassbreak Transmitter



- ▶ **DIP switches for selecting glassbreak sensitivity**
- ▶ **Four glassbreak sensitivity settings**
- ▶ **Two light emitting diode (LED) indicators**
- ▶ **Two tamper switches**
- ▶ **Test mode**
- ▶ **Dual acoustic technology**

The RF1100E Glassbreak Transmitter is a wireless transmitter that detects breaking glass. It is equipped with two tamper switches and four glassbreak sensitivity settings. When there is no alarm activity, the RF1100E transmits a signal every 15 min, providing system supervision and battery status information. The RF1100E is compatible with the RF3212E, RF3222E, and RF3227E Receivers.

## Functions

### LED Indicators

The RF1100E Glassbreak Transmitter has two LED indicators. For test purposes, the Event LED turns on when the RF1100E detects sound. The Alarm LED turns on when the RF1100E detects breaking glass. During normal operation, you can disable the LEDs to conserve battery life.

### Glassbreak Sensitivity

- Use the convenient DIP switches to select a sensitivity setting. There are four sensitivity settings: maximum, medium, low, lowest.
- Use the Event LED to help you select an appropriate sensitivity setting. When the LED flashes, the noise in the area is loud enough to initiate a glassbreak response from the transmitter.

- The RF1100E Glassbreak Transmitter has an LED ENABLE switch that activates or deactivates the LEDs. When the LED ENABLE switch is set to ON, a plastic orange tab protrudes from the side of the RF1100E Glassbreak Transmitter. The tab visually reminds you that the LEDs are active.

### Test Mode

Activate the test mode locally using the RF1100E test pads or remotely using a Bosch 13-332 Sound Sensor Tester. When the RF1100E is in test mode, use the 13-332 Sound Sensor Tester to verify that the RF1100E detects flex wave and audio signals properly.

### Dual Acoustic Technology

When an object hits a pane of glass, the glass absorbs the blow and emits a low frequency sound pressure wave, called the flex wave. When the force of the blow is too great, glass shatters and emits a high frequency audio signal. A bell ringing or a vase breaking produces a similar audio signal, but does not produce a flex wave. The RF1100E Glassbreak Transmitter detects the flex wave first and the audio signal second, reducing false alarms from items that only emit high frequency audio signals.

### Tamper Switches

The RF1100E Glassbreak Transmitter has a cover tamper switch and an optional wall tamper switch. When either switch activates, the RF1100E transmits tamper information.

### Low Battery Indication

The Event LED and the Alarm LED flash simultaneously when the RF1100E battery is low. Set the LED ENABLE switch to ON to activate the LEDs.

### Certifications and Approvals

Region	Certification
Europe	CE 1999/5/EC, EN55022: 1998 (Class B), EN60825, EN60950, EN50130-4: 1995 +A1: 1998, EN61000-4-2: 1995, EN61000-4-3: 1996, EN300220-1: 2000, EN300220-3: 2000, EN301489-1: 2002, EN301489-3: 2002
Australia	ACMA Australian Communications and Media Authority

### Installation/Configuration Notes

**Note** Glassbreak detectors are intended only as a component of a perimeter protection system. They should always be used in conjunction with motion sensors.

### Acoustic Capabilities

The RF1100E Glassbreak Transmitter can be used with the following glass types:

Glass Type	Glass Thickness
Plate	0.24 cm to 0.95 cm
Tempered	0.32 cm to 0.95 cm
Laminated	0.32 cm to 1.4 cm Protected only if both panes of unit are broken
Wired	0.64

### Sensitivity Settings

Sensitivity Setting	Range
Maximum	7.6 m
Medium	4.6 m
Low	3 m
Lowest	1.5 m

### Compatibility Information

Receivers	Control Panels
RF3212E	Solution Ultima 844, 862, and 880, CC488
RF3213E	VR-8
RF3222E	DS7400XiV4
RF3227E	DS7240, DS7220, D6412, and D4412
RF3228E	Marise
RF3249E	DA (Abacus)

### Recommended Products

- Bosch 13-332 Sound Sensor Tester
- Duracell® MN1500 or PC1500, Eveready® E91, or Panasonic® AM-3PIXB batteries

### Mounting Considerations

For the best performance, mount the RF1100E:

- On flat surfaces, such as ceilings or walls.
- Within clear view of the glass (there is no minimum range).
- Within 7.6 m of the glass.

**Note** If the window is covered with heavy drapes, curtains, shades, blinds, and so on, mount the RF1100E on the window frame.

Do not mount the RF1100E:

- In a corner or in rooms with loud equipment such as air compressors, bells, and power tools.
- On the same wall as the glass.
- On freestanding posts or pillars.

The maximum RF range of the RF1100E in an open field is approximately 300 m. In normal residential or commercial applications, mount the RF1100E within 100 m of its assigned receiver.

### Technical Specifications

#### Electrical

Battery Life:	Minimum of 2 years under normal operating conditions. Test with the recommended battery types.
Batteries:	Two AA, 3 V alkaline batteries

#### Mechanical

Dimensions	12.2 cm x 10.5 cm x 3.3 cm
Frequency:	433.42 MHz

#### Environmental

Temperature (operating):	0°C to +50°C
--------------------------	--------------

#### Trademarks

Duracell® is a registered trademark of The Gillette Company.

Eveready® is a registered trademark of Eveready Battery Company, Inc.

Panasonic® is a registered trademark of Matsushita Electric Industrial Co., Ltd.

### Ordering Information

<b>RF1100E Glassbreak Transmitter</b>	<b>RF1100E</b>
Equipped with two tamper switches and four glassbreak sensitivity settings	

#### Accessories

<b>Glassbreak Simulator</b>	<b>13-332</b>
-----------------------------	---------------



**Americas:**  
Bosch Security Systems, Inc.  
130 Perinton Parkway  
Fairport, New York, 14450, USA  
Phone: +1 800 289 0096  
Fax: +1 585 223 9180  
security.sales@us.bosch.com  
www.boschsecurity.us

**Europe, Middle East, Africa:**  
Bosch Security Systems B.V.  
P.O. Box 80002  
5600 JB Eindhoven, The Netherlands  
Phone: + 31 40 2577 284  
Fax: +31 40 2577 330  
emea.securitysystems@bosch.com  
www.boschsecurity.com

**Asia-Pacific:**  
Robert Bosch (SEA) Pte Ltd, Security Systems  
11 Bishan Street 21  
Singapore 573943  
Phone: +65 6258 5511  
Fax: +65 6571 2698  
apr.securitysystems@bosch.com  
www.boschsecurity.com

**Represented by**